


OPTIONAL ADAPTER TIPS LIST FOR MP3XXX SERIES

THE USE GUIDE OF ADAPTER TIPS



The connection diagram of output coil with tips



+



+



(Package 20) = can Charge/Power Apple Laptop G4 (14-19V)



(Package 21) = can Charge/Power Apple Laptop G3 (14-19V)



(Package 22) = can Charge/Power Dell Laptop (14-19V)



(Package 23) = can Charge/Power Dell Laptop (14-19V)



(Package 24) = can Charge/Power Dell Laptop (14-19V)



(Package 25) = can Charge/Power IBM Laptop (14-19V)



(Package 26) = can Charge/Power DSC,DV,PDVD



(Package 27) = can Charge/Power DSC,DV,PDVD



(Package 28) = can Charge/Power laptops,DSC,DV,PDVD



(Package 29) = can Charge/Power laptops,DSC,DV,PDVD



Package 27 Z tips

+



(Package 18) = can Charge/Power iPod (7.5V-12V)



Package 27 Z tips

+

(Package 1-17,19) = can Charge/Power PDA, Gameplayer, Cell phone
(The charging voltage please check their original adapter output voltage)

The connection diagram of USB output retractable cable with tips



+



+

Package 31:
USB output retractable cable



(Package 1) = can Charge/Power Black Berry cell phone

(Package 2) = can Charge/Power Motorola cell phone

(Package 3) = can Charge/Power LG cell phone

(Package 4) = can Charge/Power Samsung cell phone

(Package 5) = can Charge/Power Sony Eresson cell phone

(Package 6) = can Charge/Power Nokia cell phone

(Package 7) = can Charge/Power Siemens cell phone

(Package 8) = can Charge/Power SANYO cell phone

(Package 9) = can Charge/Power Nextel/ AUDIOVOX cell phone

(Package 10) = can Charge/Power Japan cell phone

(Package 11) = can Charge/Power Japan cell phone

(Package 12) = can Charge/Power SONY DSC

(Package 13) = can Charge/Power JVC/Samsung DSC

(Package 14) = can Charge/Power PalmOne PDA

(Package 15) = can Charge/Power Sony PDA


(Package 16) = can Charge/Power Dopod PDA

(Package 17) = can Charge/Power DELL/HP PDA

(Package 19) = can Charge/Power Game Player

(Package 35) = can Charge/Power iPod and iPhone 5V

The connection diagram of DC to DC adapter tips for input charging























Tips: These adapter tips can match all kinds of laptops originally AC power adapters , to charge our MP3XXX battery bank .


Adapter Tips List


package No.	ACON NO.	Brand Name	Buy code	Application Model No.	Quantity
For Mobile Phone					
package 1	EKP-PACKAGE01	BlackBerry	MOB-01	210/6230/6280/3510/7210/7230/7250/7280/7290/7100g/7100b/7510/7520/	2pcs
			MOB-02	BLACKBERRY 6710/6720/7270/7307/750	
package2	EKP-PACKAGE02	Motorola	MOB-03	V66/V60/V65p/V70/V120/V170/MPX200/MPX220/L300p/L72x/L73x/series/V260/V330/A760/A768/A860/T730/T720/T120/T343 /180/185/190/195/160/170/V262/V265/V260/	4pcs
			MOB-04	32N/Timeport270x/280/V200/A388/Startac/Talkabout/V998/V3688/CD928/L2000	
			MOB-05	V5/A630/A840/A845C330/C331g/c332g/T193/C331u/C333e/C343/C353u/C350/V810/T193/T22xx/V2200/V300/V400/V500/V505/V525/V551/V600/6510/7510/7520/8310/C650/V180/V188/V325/V220/	
			MOB-28	Mircro USB	
package3	EKP-PACKAGE03	LG	MOB-06	VX2000/LX1200/4NE1/1010/110/111/510/520/525/VX1/VX10/VX3100/VX4400/TP1100/5200/5250/VX4400/	4pcs
			MOB-07	G4010/G4011/G4015/G4050/G4020/C1300/L1100/L1150/L1200/L1400/VX4600/VX6000/LX5450/LX5550/LG5400/F9100/V51225/VX4500/G263/G282/232/262/G660	
			MOB-08	LG3020/VX3200/VX4650/VX4700/VX5200/VX6100/VX7000/VX8000/VX8100/VX9800	
			MOB-27	Chocolate KG800 / KG808 / MG800C / KG90 / LX150 / Chocolate VX8500 / VX9900	
package4	EKP-PACKAGE04	Samsung	MOB-09	SA288/SGH-e410/d415/d418/e315/e316/e317/SGH-r225/r225m/h625/v20x/s30x/3500/6100/8500/SGH-p107/p207/x426/x427/x427m/SGH-s300/s307/s308/SGH-c200/V206/h625/s307/x427m/P107/C207/E317/P207/X497/D307/D357/D508/D608/SCH-n105/g105/SGH-V205	4pcs
			MOB-10	SPH-1300/i300/s500/700/600/730	
			MOB-11	D800/D808/D828/D828/D820/2300/T809	
			MOB-12	A630/SCH-a850/a950/a970/a890/a790/a650/a670/n330	
package5	EKP-PACKAGE05	SONY Ericsson	MOB-13	T28/k500/p800/h700/k700i/s700i/T2xx/T3xx/T6xx/P900/R320/T29/T39/T39d/R300d/T60x/T61x/T62u/T68/T68i/z200/z500a/e00/T20/T60/T61/T62/T66/T200/T226/T237/T316/L608/L610/L616/K8300/R320SC/R330/R520m/L2218/L2288/P800/L200/L500/T637/S710a/K500i/k700i/z500w/R300ix/R300Z/T300/T306/Z600/T630/	2pcs
			MOB-14	K750i/z520a/w600/w800/W550/W900/W500/W80/	
package6	EKP-PACKAGE06	NOKIA	MOB-15	6010/6102/N70/N90/N80/82xx/83xx/88xx/6200/6230/6600/6800/6111/6100/6120	3pcs
			MOB-16	1100/1260/1261/2260/3100/3120/3200/3220/3300/3360/3390/3560/3595/Nit-Gage-010/76100/6190/6200/6230/6340/16560/6620/6682/6820/T7610/8260/8265/5060/3589/5100/6000/6015/3650/5190/	
			MOB-28	Mircro USB	
package7	EKP-PACKAGE07	Siemens	MOB-17	s155/s156/a56/c56/c156/m55/m56/a55/m55/s155/56series/A60/C60/C62/C62T/MC60/S66/SX1/C55/CF63/A65/S65/S66/C70/C71/C61/CT66/S55	2pcs
			MOB-18	C2588/C35/S35/3508/3568/3518/M35/6088/SL45/6688/6688u/3118/3508/3518/LA40/C45/3568/1118/ME45	


package8	EKP-PACKAGE08	SANYO	MOB-19	SCP-4900/5300/8100/RL2000/RL2500/R4920/5400/5500/7300/5600/200/4300/4900		2pcs	
			MOB-20	V801SA			
package9	EKP-PACKAGE09	Nextel	MOB-21	I205/I215/I265/I285/I305/I315/I530/I710/I730/I733/I830/I860/I930/I275/I325/I325s/I335/I360/I605/		2pcs	
		AUDIOVOX	MOB-22	USB 3P/6700			
package10	EKP-PACKAGE10	Japan Mobile Phone	MOB-23	Panasonic P901s/P901i/P901iv/P701i/X800		3pcs	
			MOB-24	AU/CDMA-1/TG200/CDMA			
			MOB-25	DOCOMO/PDC/P101/Digital/2100/S3/GX10/GX20/GX30			
Japan Mobile Phone							
package11	EKP-PACKAGE11		MOB-26	three Mobile phone plug (DOCOMO/CDMA/FOMA) to USB		1pcs	
For Digital Camera							
package12	EKP-PACKAGE12	SONY	DSC-01	SONY1/T828/W5/W7/V3/P200/P100/P72		4pcs	
			DSC-02	SONY2			
			DSC-03	SONY3			
			DSC-04	SONY-DV PC55E/108E/109E/350E/1000E/HC40E/1000E/R5E/21E/33E/43E/90E/20E/30E/DVD7E/602E/653E/703/803E			
package13	EKP-PACKAGE13	JVC	DSC-05	GR-DP570AC/470AC/430AC/D290AC/D270AC/750AC/GR-XSAC/D278/D258		3pcs	
		Samsung	DSC-06	t50/t5MPS3/t6PMP			
			DSC-07	Samsung DSC			
For PDA							
package14	EKP-PACKAGE14	PalmOne	PDA-01	PalmOne/Treo300/600/		3pcs	
			PDA-02	PalmOne Treo650/700/T5/Tungsten E2			
			PDA-03	PalmOne m500/505/515/130/125/705/Tungsten T/T2/Zire 71			
Package15	EKP-PACKAGE15	Sony	PDA-04	Clic'N790,NX60,NX70V,SJ20,SJ22,SJ33,TG50		1 pcs	
package16	EKP-PACKAGE16	Dopod	PDA-05	I-Mate Jam/SP3/SP5/SP5m/K-Jam		3pcs	
			PDA-06	O2 XDAII Dopod818/Dopod828			
			PDA-07	Dopod696			
				Dopod686			

package17	EKP-PACKAGE17	Dell	PDA-08	Dell-x30v/50/X50v	2 pcs
		HP	PDA-09	Mitac Mie 168/336/338/339/558 HP IPOQ h1700/1910/1915/1920/1930/1935/1937/1940/1945/2210/2215 HP IPOQ 3800/O2	
					
For ipod and game player					
package18	EKP-PACKAGE18	ipod	GAM-01	FOR Apple iPod (Charge voltage 7.5~30V) G3 generation before	1 pcs
					
package35	EKP-PACKAGE35	ipod	GAM-05	FOR Apple iPod (Charge voltage 5V) G4-video and iphone	1 pcs
					
package19	EKP-PACKAGE19	Game Player	GAM-02	Gameboy Advance SP,DS	3pcs
			GAM-03	Nintond Lite NDS	
			GAM-04	Nintondo Gameboy	
For Laptops/ Notebook Computer					
package20	EKP-PACKAGE20	Apple	Lap-01	DC NO.Q Apple Notebook G4	1pcs
					
package21	EKP-PACKAGE21	Apple	Lap-02	DC NO.G Apple Notebook G3	1pcs
					
package22	EKP-PACKAGE22	Dell	Lap-03	DC NO.F Dell Notebook Inspiron 1100/2500/2600/2650/3700/3800/4000/4100/4150/5000/C410/C500/C540/C600	1pcs
					
package23	EKP-PACKAGE23	Dell	Lap-04	DC NO.K 7.4(OD)*5.0(ID)*0.6(IP) Dell Notebook Inspiron 1150 / 300m DC NO.K 7.4(OD)*5.0(ID)*0.6(IP) HP Notebook computers NC3600/NC3840/NC6140/NC6320/NC4400/NC6120/NC2400 NX7300/7400/6115/6125/6110 NW9440/8440	1pcs
					
package33	EKP-PACKAGE33	Dell	Lap-07	DC NO.K1 7.4(OD)*5.0(ID)*0.6(IP) Dell Notebook Inspiron 8500 /1150 / 300m/500m/ 6000/ 600m/ 700m/ 8500/ 8600/9200/9300 Dell Latitude D240, D500, D600, D800 X300 D3400 D410 D500 D505 D510 D600 D610 D800 D810 Dell Precision M20 M60 M70	1pcs
					
package24	EKP-PACKAGE24	Dell	Lap-05	DC NO.O Dell Notebook Latitude 2000/2100/1400/1600/1800/15	1pcs
					

package34	EKP-PACKAGE34	IBM & Lenovo	Lap-09	DC No.L 7.9(OD)*5.5(ID)*1.0(IP) Lenovo & IBM Notebook computers		1pcs	
				LENOVO IBM Thinkpad X60 X60S X60T SERIES			
package36	EKP-PACKAGE36	HP	Lap-10	DC NO.T 4.22*1.8(Compaq) HPDV9233CL DV9000 Series		1pcs	
package37	EKP-PACKAGE37	DELL / HP	Lap-04	DC NO.K 7.4(OD)*5.0(ID)*0.6(IP) Dell&HP Notebook computers		2pcs	
			BM-KF	DC No.K(7.4*5.0*6.0)Jack to DC No.B(5.5*2.1*10.5) Plug			
package38	EKP-PACKAGE38	DELL	DC No.K1	DC NO.K1 7.4(OD)*5.0(ID)*0.6(IP)		2pcs	
			BM-KF	DC No.K(7.4*5.0*6.0)Jack to DC No.B(5.5*2.1*10.5) Plug			
package39	EKP-PACKAGE39	IBM & Lenovo	DC No.16	DC NO.L 7.9(OD)*5.5(ID)*1.0(IP) Lenovo&IBM Notebook computer		2pcs	
			BM-LF	DC No.L(7.9*5.5*1.0)Jack to DC No.B(5.5*2.1*10.5) Plug			
package25	EKP-PACKAGE25	IBM	Lap-06	DC NO.H IBM Notebook		1pcs	
Another DC Tips							
package26	EKP-PACKAGE26		DC Plug	PA-I30 3.0*1.1*11		1pcs	
				PA-L5B 5.5*1.5*12			
package27	EKP-PACKAGE27		DC No.03	PA-I23 2.35*0.7*10.5 Mobile phone, digital cameras, camcoders		3pcs	
			DC No.Z	PA-L34 3.5*1.3*10.5 Digital cameras, camcoders			
			DC No.V	PA-L40 4.0*1.7*10.5 Digital cameras, camcoders, portable DVD players, CD/MP3 players			
package28	EKP-PACKAGE28		DC No.A	PA-I47 4.75*1.7*10.5 Digital cameras, camcoders, notebook computers.		3pcs	
			DC No.B	PA-L5D 5.5*2.1*10.5 Notebook computers			
			DC No.C	PA-L5F 5.5*2.5*10.5 Notebook computers			
package29	EKP-PACKAGE29		DC No.D	PA-L63 6.3*3.0*10.5 Notebook computers		2pcs	
			DC No.E	PA-L65 6.5*4.3*1.35*10.5 Notebook computers			

DC to DC adapter tip			
package30	EKP-PACKAGE30	DCIN	BM-AF DC No.A (4.75*1.7*10.5) Jack to DC No.B (5.5*2.1*10.5) Plug
			BM-CF DC No.C (5.5*2.5*10.5) Jack to DC No.B (5.5*2.1*10.5) Plug
			BM-DF/EF DC No.E(6.5*4.3*1.35*10.5) Jack to DC No.B (5.5*2.1*10.5) Plug
			DC No.D(6.3*3.0*10.5) Jack to DC No.B (5.5*2.1*10.5) Plug
			BM-KF DC No.K(7.4*5.0*0.6) Jack to DC No.B(5.5*2.1*10.5) Plug
4pcs			

USB output retractable cable			
package31	EKP-PACKAGE31		USB to 35*13 DC Jack
			
1pcs			

GPS			
package41	EKP-PACKAGE41	For Garmin GPS	DC No.G DC No.G 3.5*1.35 Jack to Mini USB B type 5P
			
1pcs			